

FORD SENSOR BEZEL (4PCS)

FORD APPLICATIONS

MCFSNR-01



TOOLS REQUIRED

SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- .5 Hours

Time to install this should only take about half an hours.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.



STEP 1 | Sensor bezels are designed to fit in +27mm diameter holes that are 3-3.5mm in thickness.

Begin by removing the rubber isolator from the OE Ford sensor.



INSTALLATION MANUAL

STEP 2 | When installing the sensors, try to maintain the same orientation as factory.

On the bezel and sensor, there is a small notch. These must align for the sensor to seat and clip into the bezel. Note this direction prior to placing the bezel into the bumper.



STEP 3 | This shows an example of the sensor fully seated in the bezel.



STEP 4 | With the sensor removed from the bezel, place the bezel into the bumper from the front side (noting the correct orientation).

Press firmly into place until seated flush on the front side of the bumper.



INSTALLATION MANUAL

STEP 5 | Holding the bezel in place, insert the sensor into the bezel from the backside until it “clicks” into place and is secure.



STEP 6 | Once all are set into place, reconnect sensor and check to ensure orientation is correct and sensor is evenly spaced in the bezel.

