

OVER HEAD MOLLE PANEL

18+ JEEP JL/JT

MPJL-04



TOOLS REQUIRED

- T25, T40 Torx Tool
- #5, #6 Allen Tool
- 13mm, 17mm wrench
- Trim Tool
- Safety Glasses

SKILL LEVEL

- Novice/Intermediate
 - 1 (you) to 2 persons
- Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- 2.5 Hours
- Time to install this should only take about two and half hours.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover




INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (4) M10x55 Allen Head Bolts
- (4) M10 Nylon Lock Nuts
- (8) M10 Flat washers
- (2) M8x20 Allen Head Bolts
- (2) M8 Nylon Lock Nuts
- (4) M8 Flat Washers



STEP 1 | Lay the two over head molle panel pieces on a covered work bench as shown.




STEP 2 | Using a #5 allen tool and a 13mm wrench with the provided M8x20 hardware, secure the two panels together.

Use (1) M8 flat washer on the allen bolt head and (1) M8 flat washer on the nylon lock nut side.



INSTALLATION MANUAL



INSTALLATION MANUAL

STEP 3 | Remove the vehicles freedom panels.

Using a T25 torx tool, remove the (5) torx head bolts that secures the trim panel to the roll cage cross bar.



STEP 4 | With a firm grip carefully pull down on the roll cage cross bar trim panel to expose the freedom panels latch catches hardware.



INSTALLATION MANUAL

STEP 5 | Use a T40 torx tool to remove the freedom panel latch catches as shown.




STEP 6 | Place the DV8 over head molle panel on top of the roll cage.



INSTALLATION MANUAL

STEP 7 | Using the factory hardware and a T40 torx tool secure the rear molle panel mounting plates between the roll cage cross bar and freedom panel latch catches.



STEP 8 | Using a t25 torx tool secure the trim panel to the roll cage cross bar.



INSTALLATION MANUAL

STEP 9 | Thread the provided M10x55 allen head with M10 flat washer through the molle panel mounting bracket and through the roll cage.

Loosely secure the M10 hardware using the provided M10 flat washers and M10 nylon lock nuts.

Secure the M10 hardware using a #6 allen tool and 17mm wrench.



STEP 10 | Loosely secure the M10 hardware using the provided M10 flat washers and M10 nylon lock nuts.

Secure the M10 hardware using a #6 allen tool and 17mm wrench.



INSTALLATION MANUAL

STEP 11 | Double check that all hardware is secure.

Congratulations, installation of the DV8 JL/JT Over Head Molle Panel is now complete.

